

## FCC INFORMATION

B66  
FCC ID: EM0B66N  
IC: 986B-B66N  
HVIN: XX-B66Na

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

• Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

• NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

CAN ICES 3(B) / NMB-3(B)

## CANADA STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:


(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



### Limited 90-Day Warranty Information

eKids, LLC, warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, eKids will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by Customer Service.

If service is required, please call Customer Service at 1-800-288-2792 to obtain a Return Authorization Number and shipping instructions.

#### Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CDs or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will eKids or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your eKids product.

Questions? Visit [www.ekids.com](http://www.ekids.com)  
For other questions: 1-800-288-2792 Toll Free  
©2020 SDI Technologies, Inc. All Rights Reserved.  
iHome is a registered trademark of SDI Technologies Inc., used under license.


Ti-B66MR-041720-A

Printed in China


## Maintenance:

- Place unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents can damage the surface of the unit.

## What's Included:



## Controls




When not in use, slide Power Switch to the OFF position to save battery power.

## Charging the Unit

### CHARGE UNIT BEFORE USE

1. Connect the micro USB plug to the micro USB charging port on the back of the unit.




2. Connect the standard USB plug end of the cable to a power USB port on a computer or other USB charging device. For first time use, charge unit for about 5 hours.
3. The Power/Charging/Pairing LED on the back of the unit glows red steadily while the unit is charging and turns OFF once the unit is fully charged. If unit is not powered on when micro USB plug is connected, the red light glows steadily to indicate unit is charging.


## Maintenance

- Tenez l'appareil sur une surface plane hors des rayons directs du soleil ou de toute chaleur excessive.
- Protégez vos meubles quand vous posez l'appareil sur du bois naturel ou sur une surface laquée. Un tissu ou un autre matériau de protection doit être placé entre l'appareil et le meuble.
- Nettoyez votre appareil uniquement avec un tissu doux et un peu de savon doux. Les agents nettoyants tels que le benzène ou autres détergents pourraient endommager la surface de l'appareil.

## Ce qui est inclus:



## Les contrôles




Lorsque l'appareil ne va pas être utilisé, positionnez le commutateur sur OFF pour économiser la batterie.

## Recharge de l'unité

### CHARGEZ APPAREIL AVANT UTILISATION

1. Branchez le connecteur micro USB dans le micro-port USB de charge situé à l'arrière de l'unité.



2. Connectez l'extrémité USB standard du câble à un port USB alimenté d'un ordinateur ou d'un autre appareil de charge USB. Pour la première fois, chargez l'unité pendant environ 5 heures.
3. La voyant Alimentation/Charge/Couplage indicateur lumineux à l'arrière de l'unité s'allume en rouge de façon constante pendant que l'unité est en charge et s'éteint une fois que l'unité est complètement chargée. Si l'unité n'est pas allumée lorsque le connecteur micro USB est connecté, le témoin rouge reste allumé pour indiquer qu'elle est en charge.

## Coupler votre appareil

Le couplage est un processus qui permet la présentation de votre dispositif compatible Bluetooth à Ti-B66MR. Une fois votre dispositif couplé, Ti-B66MR peut le reconnaître et vous pouvez écouter vos fichiers audio à travers l'unité.

1. Assurez-vous que votre appareil Bluetooth est complètement chargé. Allumez votre appareil Bluetooth et le rendre « détectable » en activant le mode Bluetooth (reportez-vous aux Options ou Réglages).

## Pairing Your Device

Pairing is the set-up process to introduce your Bluetooth-capable device to the Ti-B66MR. Once your device is paired, the Ti-B66MR can recognize it and you can play your audio through it.

1. Make sure your Bluetooth device is fully charged. Turn on your Bluetooth device and make it "discoverable" by turning on Bluetooth mode (check in Options or Settings).
2. Slide the Power ON/OFF Switch to ON to turn on the Ti-B66MR. The first time the unit is powered on, it will enter auto-pairing mode and attempt to connect to a Bluetooth device (if so, skip to step 4).
3. Press and hold the Bluetooth pairing button for 3 seconds. The Ti-B66MR will beep and the Power/Charging/Pairing LED on the back of the unit will flash red and blue.
4. "iHome B66" should appear in your device's Bluetooth menu. If "Not Paired", "Not Connected" or similar message appears, select "iHome B66" to connect it. If prompted for a passcode, enter "1234" on your device's keypad.
5. If pairing is successful, a tone will sound and the blue LED will glow solid, indicating the Ti-B66MR is ready to play music. There should also be an indication on your device. Once the Ti-B66MR is paired to a device, it will attempt to auto-link when the device is within range (about 30 feet).

## Pairing with a Different Device

When the speaker is ON, it will automatically link with the previously paired Bluetooth device as long as that device is still within range (approx. 30 feet). So to pair with a different device you must press and hold the Bluetooth pairing button for 3 seconds to re-enter pairing mode.

## Playing Audio Via Bluetooth

1. Move the ON/OFF Switch to the ON position to listen to audio streamed wirelessly from your paired iPad, iPhone, iPod or other Bluetooth device. The Power/Charging/Pairing LED on the unit will flash blue and a tone will sound as the unit searches for a previously paired device, and then turn solid blue once a previously paired device is detected.
2. Use the controls on your Bluetooth device to play or pause audio, navigate tracks and control volume.
3. When done listening, move the ON/OFF Switch to the OFF position to conserve the battery.

## Troubleshooting

#### Unit doesn't respond (no power):

- Make sure unit is completely charged.
- Check that all connections are correct and properly plugged in.
- Make sure your device is properly paired with the Ti-B66MR.
- Make sure the ON/OFF Switch is not in the OFF position.
- The rechargeable battery in your speaker can be replaced only by eKids Consumer Repair Department.

#### Unit doesn't respond (locked up/ "frozen")

If the unit does not respond, try resetting it. Press and hold the Bluetooth pairing button for 9 seconds. Note that doing so will clear settings, and any Bluetooth devices will need to be re-paired.

#### Troubleshooting device with Ti-B66MR

Bluetooth implementation varies depending on your device's hardware and operating system. Please see our website for updates on pairing.

- When you power ON the speaker, it will automatically link with the last previously paired Bluetooth device if the device is still within range (approx. 30 feet). To pair with a different device you must turn off Bluetooth capability on the already paired device, or take it out of range.
- If your device does not auto-link when within range, re-pair the device. To do so, first delete the Ti-B66MR from your Bluetooth devices menu.

For further information and to see the latest instructions, visit [www.ekids.com](http://www.ekids.com)

## Enoncé FCC

B66  
FCC ID: EM0B66N  
IC: 986B-B66N  
HVIN: XX-B66Na

Cet équipement est conforme aux limites d'exposition aux radiations de la FCC RF fixées pour un environnement non contrôlé.

Cet appareil est conforme à la section 15 des règlements de la FCC, son utilisation est soumise à deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences nuisibles et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent causer un mauvais fonctionnement.

• Avertissement : Tout changement ou modification apporté à cet appareil sans le consentement express de la partie responsable pour la conformité peut annuler le droit de l'utilisateur d'utiliser cet appareil.

• REMARQUE : Cet équipement a été testé et jugé conforme aux limites pour un appareil numérique de Classe B, selon la Section 15 de la réglementation FCC.

Ces limites sont conçues pour offrir une protection raisonnable contre les interférences nocives d'une installation résidentielle. Cet équipement génère, utilise et peut émettre des fréquences radio élec., si l'il n'est pas installé et utilisé selon les instructions, peut causer des interférences nuisives aux communications radio.

Cependant, il n'y a aucune garantie qu'une interférence ne prendra place dans une installation particulière. Si cet équipement ne cause pas d'interférence nocive à la réception de la radio ou du téléviseur, ce qui peut être déterminé en allumant et fermant l'équipement, l'utilisateur est encouragé à tenter de corriger l'interférence en utilisant l'un ou l'autre des moyens suivants :

• Réorientez ou réajustez l'antenne de réception.

• Augmentez la séparation entre l'équipement et le récepteur.

• Branchez l'équipement dans une prise d'un circuit différent que celui dans lequel est branché le récepteur.

• Consultez le marchand ou un technicien expérimenté en radio/téléviseur pour obtenir de l'aide.

CAN ICES-3 (B)/NMB-3(B)

## Déclaration d'Industrie Canada (IC)

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si ce brouillage est susceptible d'en compromettre le fonctionnement.

Ce matériel est conforme aux limites d'exposition aux rayonnements de ffr et de ffc énoncées dans un autre environnement.

Ce matériel doit être installé et exploité à une distance minimale de 20 cm entre le radiateur et votre corps.

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité pourrait annuler le droit de l'utilisateur à utiliser l'équipement.

Consultez le client au numéro 1-800-288-2792 pour obtenir le numéro de Autorisation de Déviation et les instructions de dépôt.

Cette déclaration de la conformité est faite en vertu de la section 43.11 de la Réglementation sur les appareils radio et de la section 43.11 de la Réglementation sur les appareils de télécommunications.

Ce matériel doit être installé et exploité à une distance minimale de 20 cm entre le radiateur et votre corps.

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité pourrait annuler le droit de l'utilisateur à utiliser l'équipement.

CAN ICES-3 (B)/NMB-3(B)

## DECLARATION DE CANADA


Cet dispositif contient transmetteur exempt de licence (s) / récepteur (s) que cumple la Innovación, Ciencia y RSS exentos de licencia de Desarrollo Económico Canadá (s) operación está sujeta a las dos condiciones siguientes:

(1) este dispositivo no puede causar interferencias,

(2) este dispositivo debe aceptar cualquier interferencia, incluyendo interferencias que puedan causar un funcionamiento no deseado del dispositivo.

Este dispositivo cumple con los límites de exposición de radiación IC RF establecidos para un entorno no controlado.

Cualquier cambio o modificación no aprobada expresamente por la parte responsable del cumplimiento podría anular la autoridad del usuario para operar el equipo.



### Informations limitée de 90 jours de garantie

eKids, LLC une filiale propriété exclusive de KIDdesigns, garantit que ce produit est exempt de tout vice de fabrication et de matériaux, dans des conditions normales d'utilisation, pendant une période de 90 jours à compter de la date d'achat initiale.

Si cet appareil ne fonctionne pas de manière satisfaisante, il est préférable de le débrancher et de débrancher, puis de débrancher, puis de débrancher